

TABLE OF SW SETTINGS IN P400

PC board INTCON:

<u>SW No.</u>	<u>Open</u>	<u>Closed</u>
8	EXTCON installed	EXTCON not installed
7	Cas. initiated	Disabled
6	CVA2 installed	VA1 installed
5	Siemens PT88 printer	Olivetti TH240 printer
4	Polarity skipped	Polarity performed
3	Unused	Unused
2	Power up selftest	Skip selftest
1	User mode	Debug mode
	Select: N	Deselect: N
9+10	New cabling in P400 for keybox	Old cabling in P400 for keybox

PC boards CPU and CPU 2.0:

<u>SW No.</u>	<u>Open</u>	<u>Closed</u>
1	Normal	Reset the CPU

PC board EXTCON:

<u>SW No.</u>	<u>Open</u>	<u>Closed</u>
1	$\overline{\text{CTS}}$ valid	$\overline{\text{CTS}}$ forced from terminal

S1 (O = Open)

<u>Baud Rate</u>	<u>A</u>	<u>B</u>	<u>C</u>	<u>D</u>	<u>E</u>	<u>F</u>	<u>G</u>	<u>H</u>
300	$\overline{\text{O}}$	$\overline{\text{O}}$	$\overline{\text{O}}$	$\overline{\text{O}}$	$\overline{\text{O}}$	$\overline{\text{O}}$	$\overline{\text{O}}$	$\overline{\text{ON}}$
600	O	O	O	O	O	O	ON	O
1200	O	O	O	O	O	ON	O	O
2400	O	O	O	O	ON	O	O	O
4800	O	O	O	ON	O	O	O	O
9600	O	O	ON	O	O	O	O	O
19200	O	ON	O	O	O	O	O	O
38400	ON	O	O	O	O	O	O	O